

General guidelines for Vehicle Chevrons:

Often customers are not able to supply actual vehicles, and so we use digital images from our vehicle library. We need the following information to match your vehicle to one in our library:

VEHICLE MAKE

VEHICLE MODEL

YEAR

TYPE - SALOON/HATCH/ESTATE

If your vehicle is a van, please state: HI/MED/LO ROOF

REAR WINDOWS or SOLID PANEL

Supplying photos:

Where no clipart vehicle templates are available, customers should provide photos of the rear of the vehicle for us to work from.

It is important to take the photo from the correct angle:

Stand 6 to 10 feet directly behind the vehicle, centrally positioned. Kneel down so that the camera is pointing at the middle of the boot hatch. Use the camera 'Zoom' to fill the frame.

Take several photos so we can choose the best one.

Provide measurements of the width and height of the boot hatch as shown below: (Widest & deepest point)



Magnetic & self adhesive chevrons are made from stiff material which will only sit safely on flat panels, and not bend around panel contours. Take additional photos from the side to show any panel contours, dips or extrusions. We may supply your chevrons in several pieces to accommodate panel contours.

Checking drawings

We will supply you with a detailed drawing of the chevron panel, complete with detailed measurements. It is essential that you **CHECK THESE MEASUREMENTS AGAINST YOUR VEHICLE** before you approve the artwork.

NOTE: All chevron panels drawn up from supplied photos will need to be amended before approval - photos alone do not provide enough accuracy.